

WD-MJ-A1 SERIES USER SMANUAL FFPFFfb



GUANGZHOU WEIDE ELECTRIC MACHINERY CO., LTD.



Content	

1. Mode Specifications2
2. Wiring
2.1 Basic Running Wiring Connection3
2.2 Strong Current Terminal Definition4
2.3 Control Terminal Connection4
2.3.1 Input Control Terminal4
2.3.2 Input Terminal Other Parameters5
2.3.3 Output Control Terminal5
2.3.4 Output Control Terminal Optional Parameters5
3. Door System Parameters6
3.1 Command Parameters6
3.2 Advanced Parameters7
4. Panel Debugging8
5. Control Parameter Setting Process15
5.1 Common Parameters15
5.2 Advance Parameters15
5.3 Encoder Parameters15
5.4 Port Parameters16
5.5 Motor Parameters16
Appendix Table 1 - Alarm Signal16
Appendix Table 2 - Motor Code17

1. Mode Specifications

lt N	em Aodel	WD-MJ-A1-075	A1-075 WD-MJ-A1-10 WD-MJ-A1-15		WD-MJ-A1-22			
Adaptive motor power (KW)		0.75	1.0	1.5	2.2			
	Rated							
	Voltage	AC220V-50Hz/60Hz						
Power	(V)							
Supply	Allowable							
	Variation	Voltage: \pm 20% Voltage Imbalance Rate <3% Frequency: \pm 5%						
	Value							
	Input							
	Current(A)	0.2	7.5	5.5	15.5			
	Rated	4.5	55	75	10.5			
	Current(A)	4.5	5.5	7.5	10.5			
Output	Maximum							
	Voltage(V)		corresponds to	the input voltage				
	Maximum							
	Power(KW)	2.5						

2.Wiring

2.1Basic Running Wiring Connection

The basic wiring diagram of the controller is shown in the figure:



2.2 Strong Current Terminal Definition

Note: These terminals contain AC220V strong electricity, please do not plug or unplug

while the power is on!

Terminal Name	Function Description		
PE	Protective ground terminal		
L _N N	Single-phase AC power input terminal AC220V-50/60Hz		
U, V, W	Motor three-phase AC output terminals		
B1、B2	Motor brake control terminals		
P、 DB	Brake resistor		

2.3 Control Terminal Connection

2.3.1 Input Control Terminal

Input Terminal	Parameter No.	Function	Default	Description
X1	PA1-0	0=NONE Non-function	1=OPD Open door signal	
X2	PA1-1	1=OPD Open door signal	2=CLD Close door signal	
Х3	PA1-2	2=CLD Close door signal	3=EMC Emergency stop	
		3=EMC Emergency stop signal	signal	
X4	PA1-3	4=SUL Set upper limit signal	35=Learning mode/Normal	In normal mode, both
		5=SDL Set lower limit signal	working mode	manual/automatic are enabled
X5	PA1-4	6-31 Reserve	36=Radar signal	Radar/Geomagnetic signal: In
		20=SON		normal working mode, the
		21=ALRS		controller automatically opens the
		22=FSTP		door after receiving this signal.
		23=RSTP		After a fixed delay time, the door
		24=CLE		will automatically close.
		25=INH		Re-filtering, edge effective.
X6	PA1-5	26=FIL	37=Photoelectric signal	Photoelectric/airbag signal: During
		27=RIL		the process of closing the door, if
		32=UPL Upper limit switch		this signal is input, the door will be
		33=DNL Lower limit switch		reopened immediately.
		34=FH Fully open/Half open		Re-filtering, edge effective.
X7	PA1-6	35=MA Learning mode/Normal	32=Upper limit switch	
X8	PA1-7	working mode	33=Lower limit switch	
Х9	PA1-8	36=RADAR Radar, Geomagnetic signals	4=SUL Set upper limit	
		37=PHO Photoelectric signal	signal	
X10	PA1-9	38=JOG Demo run	5=SDL Set lower limit signal	
		39=PURO Rope switch		
		40=ZERO Origin return switch		

Parameter No.	Bit4	Bit3	Bit2	Bit1	Bit0
	0010	0008	0004	0002	0001
PA1-20	SDL	SUL	EMC	CLD	OPD
PA1-21	CLE	RSTP	FSTP	ALRS	SON
PA1-22	x	х	RIL	FIL	INH
PA1-23	x	MA	FH	DNL	UPL
PA1-24	RADAR	ZERO	PURO	JOG	РНО

2.3.2 Input Terminal Other Parameters

2.3.3 Output Control Terminal

Output Terminal	Parameter No.	Default	Description
Relay 1	PA1-30	11	11=Reach the lower limit
Relay 2	PA1-31	12	12=Leave the lower limit
Relay 3	PA1-32	0	0=No output, forced OFF

2.3.4 Output Control Terminal Optional Parameters

No.	Function	Description		
0	NONE: No output, forced OFF	Relay 3 selects this option by		
		default		
1	SRDY: Device ready			
2	RUN: Running			
3	ALM: Fault output			
4	Forced ON			
5	COIN			
6	BRK			
7-10	Reserve			
11	ON_LP: Reach the lower limit	Relay 1 selects this option by		
		default		
12	OU_LP: Leave the lower limit	Relay 2 selects this option by		
		default		
13	ON_TP: Reach the upper limit			
14	OU_TP: Leave the upper limit			
15	OING: Opening the door			
16	CING: Closing the door			
17	LINE: Linked door signal, that is, when			
	one door is closed, the other door			
	automatically opens			
18	TO_LP: When it reaches the lower limit			
	1, the automatic mode will output			

3. Door System Parameters

No.	Parameter Name	Description	Factory	
PA1-50	Work mode	0=Learning mode, setting upper and lower limit values, triggering by door switch signal level 1=Normal working mode, responds to opening, closing doors, radar signals, and edge triggering. After opening the door triggered by the radar signal, the door will be closed automatically. During the closing process, there will be a photoelectric signal and the door will be reopened.	0	
PA1-51	Door opening speed	1-4500rpm	2250	Normal mode, manual, automatic, demonstration speed
PA1-53	Door closing speed	1-4500rpm	1500	Normal mode, manual, automatic, demonstration speed
PA1-54	Return to zero reset door closing speed	1-4500rpm	600	Speed during zero return and reset
PA1-55	Opening door acceleration (deceleration) speed	0.0-100.0 s	0.5s	Acceleration (deceleration) speed, the larger the value, the faster the acceleration and deceleration
PA1-57	Closing door acceleration (deceleration) speed	0.0-100.0 s	15	Acceleration (deceleration) speed, the larger the value, the faster the acceleration and deceleration
PA1-61	Automatic drop delay time	0.0-3600.0 s	10s	In normal working mode, after the radar signal starts opening the door, it will automatically close the door after a delay of this time.
PA1-62	Door opening and closing time limit	0.0-3600.0 s	120s	

3.1 Command Parameters

PA1-64	Number of pulses at lower limit position	0-32000	0	In learning mode, after the lower limit is set by operation, this value is set to 0
PA1-65	Mid-limit position pulse number	0-32000	10000	After setting the upper and lower limits, it will automatically be calculated based on 50%
PA1-66	Upper limit position pulse number	0-32000	20000	In the learning mode, after the upper limit is set by operation, it is set to the current actual value.

3.2 Advance Parameters

No.	Parameter Name	Description	Factory	
			Default	
PA1-68	Learning mode speed	The larger the value, the	100	
	acceleration time	slower the acceleration.		
PA1-70	Limit learning	1-750rpm	600	
	running speed			
PA1-75	Demo door opening	Set the delay time for	10	Unit 0.1s
	and closing delay	automatic demonstration		
		to open and close the door,		
		0.0-3600.0		
PA1-76	Motor running	0=Run in default direction	0	
	direction	1=Reverse direction		
PA1-80	Mode selection	0=Roller door		
		1=Louvre door		
PA1-82	Brake delay closing	0.0-100.0s	1.0	
	time			
PA1-83	Limited number of	After the number of door	0	
	door openings	openings is reached, the		
		controller will stop running,		
		0-30000, 0=does not work		
PA1-84	Clear the number of	Clear the cumulative	0	
	door openings	number of door openings		
		0=Do not perform the		
		operation		
		1=Clear		
PA1-85	Language selection	0=Simplified Chinese,		
		1=Traditional Chinese,		
		2=English		

PA1-99	Save EEPROM switch	0=Run without storing	0	EEPROM has a storage life
	during operation	location. (The system will		
		store the position twice		
		when powering off)		
		1=When opening and		
		closing the door, the		
		position is saved once		
		every 5 seconds. After the		
		door is opened and closed,		
		the position is saved twice.		

4.Panel Debugging

The panel consists of 9 function buttons and LCD display as shown in the figure below:



4.1 Function Key Description

Menu: This button is used to enter the main menu screen. At the same time, it is used as the return button after modifying parameters to return to the previous menu or exit the menu;

OK: This button is used to enter the submenu of the main menu after entering the menu. After modifying the parameters, confirm the parameter modification and return to the submenu of the modified parameters;

Reset: used for alarm clearing;

Inc/UL: Used to select the corresponding menu upward after entering the menu, and adjust the parameter value to increase after entering the parameter modification interface. In the manual/learning interface, you can press and hold for 2 seconds to set the upper limit position;

Dec/DL: Used to select the corresponding menu downwards after entering the menu, and adjust the parameter value to decrease after entering the parameter modification interface. In the manual/learning interface, you can press and hold for 2 seconds to set the lower limit position;

A/M: Used to switch the mode and status of the door operator. There are two types: ①-Auto/Normal, ②-Manual/Learning;

▲: This button is used to control the rapid door opening;

STOP: This button is used to control the rapid door stop;

▼: This button is used to control the fast door closing;

4.2 Debugging Interface Description

Main menu: Press the menu key to enter the main menu as shown below, and press the confirmation key to enter the next-level menu of the main menu. There are 5 main menus in total, including common parameter group, advanced parameter group, encoder parameter group, port parameter group, and motor parameter group.



Boot interface: Enter this interface after powering on.



Automatic control interface: Press the automatic/manual button to enter the automatic state mode. In this mode, the door operator can be controlled by remote control, photoelectric, radar and other signals.



Parameter selection interface: This interface can quickly select preset

parameters.

Select Speed:			
0.High			
$Press \land \lor$ Done			

Parameter setting interface: This interface can set corresponding parameter values (such as: door opening and closing speed, door opening and closing acceleration time, encoder parameters, motor parameters, etc.).



Upper limit setting interface: This interface displays whether the upper limit setting is successful.



Lower limit setting interface: This interface displays whether the lower limit setting is successful.



Door closing interface: This interface displays the door closing position.



Door opening interface: This interface displays the door opening position.



Stop interface: This interface displays the stop position.



Alarm display interface: This interface displays various alarm signals. (Such as:

encoder failure, encoder disconnection, bus voltage undervoltage, etc.)



5.Control Parameter Setting Process

5.1 Common Parameters

Menu key -> increase/decrease button selection -> confirm -> enter the common menu parameter group -> select the parameters that need to be changed -> increase/decrease button setting -> confirm and exit after completion.

5.2 Advance Parameters

Menu key -> increase/decrease button selection -> confirm -> enter the advanced menu parameter group -> select the parameter that needs to be changed -> increase/decrease button setting -> confirm and exit after completion.

5.3 Encoder Parameters

Menu key -> increase/decrease button selection -> confirm -> enter the encoder menu parameter group -> select the parameters that need to be

changed -> increase/decrease button setting -> confirm and exit after completion.

5.4 Port Parameters

Menu key -> increase/decrease button selection -> confirm -> enter the port menu parameter group -> select the parameters that need to be changed -> increase/decrease button setting -> confirm and exit after completion.

5.5 Motor Parameters

Menu key -> increase/decrease button selection -> confirm -> enter the motor menu parameter group -> select the parameters that need to be changed -> increase/decrease button setting -> confirm and exit after completion.

Alarm Name	Alarm Reason	Alarm Check Remark	
Bus voltage	Power supply	Check under-voltage	
undervoltage	undervoltage	settings and voltage	
		measurements on power	
		lines	
Bus voltage	Power supply	Check over-voltage settings	
overvoltage	overvoltage	and voltage measurements	
		on power lines	
IPM module	IPM module is damaged	Power off and restart. If the	
failure	or over-temperature	fault persists, it means the	
	protection	IPM module is damaged.	
Input phase	The input power cord is	The power cord has poor	
loss	disconnected or has	contact or the line is	
	poor contact.	disconnected or has a	
		power outage.	
Running	The current exceeds the	Check the current settings,	
overcurrent	limit current	power off and restart or	
		check the current sampling	
User torque	Stalled rotor or	Check whether the device is	
overload	overloaded	stuck	
Running	The load exceeds the	Overloaded or replace with	
overload	rated value	a larger drive	

Appendix Table 1-Alarm Signal:

EEPROM error	E ² ROM chip is	Power off and restart.If the	
	damaged or the	fault persists, it means the	
	number of writes	chip is damaged.	
	exceeds the limit.		
Encoder failure	Encoder error	Encoder mismatch	
Motor	The speed exceeds the	Check speed limit settings	
overspeed fault	rated speed		
Encoder	The encoder is	Check that the connecting	
disconnection	damaged or the	cable or encoder is	
	connecting wire is	damaged	
	disconnected		
Bleed brake	The bleeder resistor is	The bleeder resistor is	
failure	damaged or has poor	damaged or has poor	
	contact.	contact.	

Appendix Table 2-Motor Code:

Setting process: Menu->Motor parameter group->Motor parameter

setting->Increase/decrease setting parameters->Confirm and exit.

Motor Type	Encoder Type	Motor Code
0.75KW Absolute motor	Single-turn 17bits	156
1.0KW Absolute motor	Single-turn 17bits	157
1.5KW Absolute motor	Single-turn 17bits	To be confirmed
2.2KW Absolute motor	Single-turn 17bits	To be confirmed